


USB keyboard emulator



Device use Power from USB PC cable.

Examples of used keys:

Key_1	0	Key_1	TAB SelectGame
Key_2	1	Key_2	1 1line
Key_3	2	Key_3	2 3line
Key_4	3	Key_4	3 5line
Key_5	4	Key_5	4 7line
Key_6	5	Key_6	5 9line
Key_7	L	Key_7	ENTER START button
Key_8	S	Key_8	7 Bet one RED
Key_9	9	Key_9	8 Info/Help
Key_10	6	Key_10	9 MaxBet Black
Key_11	7	Key_11	Home Denom+
Key_12	8	Key_12	CapsLock AutoStart
Key_13	Right arrow	Key_13	SPACE START button
Key_14	ENTER	Key_14	Pad* AutoStart
Key_15	ESCAPE	Key_15	Pad/ SelectGame
Key_16	SPACE	Key_16	End Denom-